


**Model#: Cab-FA122-BK
Cab-FA122-WH**


ASSEMBLY INSTRUCTIONS
INSTRUCTIONS D'ASSEMBLAGE




Max load: 8kgs During Moving

Charge maximale : 8 kg pendant le déplacement


► SCREW PACKAGE / PAQUET DE VIS





► PARTS INCLUDED / PIÈCES INCLUSES




► INSTALLATION / INSTALLATION





3



4




5



6

Lockable caster
Roulettes verrouillables



Warning: When the ground is uneven and you feel the table is shaking, please adjust the wheels to make it flat.



Avertissement : Lorsque le sol est irrégulier et que vous sentez que la table tremble, veuillez régler les roulettes afin de la mettre bien à niveau.