


Cab-DLB507 Installation guide





VESA
100x100
75x75

17°-30°


2-9kg

-85°-15°




STEP1 Preparations Before Installing The Monitor


1. Check if the installed monitor has installation holes (with 100x100 or 75x75). If there are no installation holes, the bracket cannot be installed. (Note: Some of the display mounting holes are used to install the original fixed base and are detachable.)
2. Remove the original fixed base of the monitor (the method varies depending on the monitor). During the entire removal process, please avoid scratching the monitor panel with hard objects.




STEP3 Main Body Connection




STEP4 Display Connection




STEP2 Table Board Connection



STEP5 Cable Organization



STEP6 Organizing tools



 Warning

This product contains small items that could be a choking hazardif swallowed. Keep these items away from young children

- Make Sure these instructions are read and completely understood before attempting installation. If you are unsure of any part of this installation, please contact a professional installer for assistance
- The desktop installation must be able to bear the weight of the stand and the monitor. Otherwise, please strengthen the structure of the desktop in time to consolidate its load-bearing capacity.
- please check joint parts every two months, making sure the screws are loosened or not.

This product was designed to be installed on desk. Before installing, make sure the mount will support the combined load of the equipment and hardware. Never exceed the maximum load capacity 9 KG, or else it may result in product failure or personal injury

Note: this product is intended for indoor use only. Use of this product outdoors could lead to product failure or personal injury.

Warning: This product contains high pressure gas spring parts, do not put into the fire, high temperature baking or private disassembly, otherwise it may cause unpredictable personal injury. Please send the product back to the original factory or hand it over to a professional organization for disposal. In order to ensure the sealing performance of the gas spring, it is recommended that the upper arm of the product (spring arm) be adjusted once or several times a month.

Warning: For safety reasons, always use the accessories that come with the product.

Waste disposal



This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.